



AIM5000

REPAIR KIT

- It contains five pieces of pvc fabric and a bottle of special glue:
- Make sure the damaged spot is not covered with oil or grease, clean it thoroughly and make it rough
- Apply the special glue and let it dry (check with the back of the fingers)
- Apply the fabric with firm pressure to that area. Check the seal

For further information and/or technical data related to the product, please refer to the Oscar Boscarol Company.